

1. Place the extension cap to the spoiler for the initial fitment.

2. Place masking tape on the car spoiler at the extension cap edges that will be used for marking the placement of the part.

3. Use measuring tape to find even distances from the reference points of your car to the edges of the extension cap (ask for assistance to hold part in place while taking measurement)
Make sure that distances measured from the left and the right side are equal. We do not recommend finding the center point of the extension cap and the spoiler since it will make correct fitment more difficult.



4. Outline the edges of the extension cap on the masking tape.

5. Put the extension cap to the side.
Use provided degreasing cloth to clean the spoiler prior installation.

6. Remove 2-3cm of the foil from the double sided mounting tape at the edge of the extension cap.

If the car has a ceramic coating or PPF foil, remove a piece of the coating or foil where the spoiler is mounted.



7. Place the extension cap at the both points that you marked on the masking tape (as described in point 4 of this manual).



8. Slowly remove the rest of the foil from the double sided mounting tape holding extension cap in the marked place of fitment and applying pressure (ask someone for assistance to prevent part from movement)



9. Remove the protective foil from the part.



10. Use the heat gun to slightly heat the extension cap, so the mounting tape sticks well to the surface of the spoiler. Be cautious not to use excessive heat or if possible set the heat to a minimum. Keep 30-40cm distance while heating the extension cap. Overheating could cause damage to the product.

